



## **145 Retell BT Telephone Wall Socket Connector**



For connection of analogue telephones between the wall socket and the line plug of the telephone. It will record from analogue PABX extension sockets but it will not work on digital PABX extension sockets

Included in Retell kits 120

If your connector is supplied with two double adaptors then one is for use with BT style sockets and one for use with analogue extensions with RJ45 sockets.

1. Take the white cable and plug the smaller of the two clear plugs into the socket on the black connector box (it has the writing 'Retell Telephone Recording Connector' on it). Plug the other clear plug into the white adapter BT double adaptor or the beige RJ45 double adaptor depending upon your telephone socket.
2. Unplug the line cord of the telephone you wish to connect from the telephone wall socket and plug the telephone plug into the spare socket on the white adapter. Plug the white adapter into the telephone wall socket - your telephone will now be connected to the telephone wall socket through the white adapter. Plug the silver 3.5mm jack plug from the 145 connector into the socket on the recorder marked with a "Ⓜ" or MIC.
3. Press the RECord button down to start recording. Switch AUTO/VOX to 1 (on) to switch the recorder on and off automatically for each call.

**As with all Easy Fit connectors, the BT Telephone Wall Socket Easy Fit connector is not recommended for connection to computers. Please use the Easy Fit connector suitable for use with a PC (Retell part number 157 with 142) instead.**